

Crossroads Linear Suspension

700LSCRSS_ 1.1



CEILING

GENERAL PRODUCT INFORMATION:

This fixture is intended to be installed utilizing NEC compliant junction boxes.




This product is suitable for dry locations only.


CAUTION - RISK OF FIRE
 This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
 Use minimum 90°C supply conductors.




Install the Mounting Plate



1 Separate the mounting plate from the canopy by removing all four screws.




2 Remove the mounting plate from the canopy.



3 Secure the mounting plate to the electrical box with the two #8-32 screws provided.


Install the Fixture

1D




- 4 Line up an anchor with the center of a backplate hole and push the anchor in up to the threads.
- 5 Screw the anchor the rest of the way in with a screwdriver.

1E




- 6 Secure the backplate to the anchor with a screw and washer.
- 7 Repeat steps 4-6 for the remaining anchor hole.

2A




NOTE: Make sure to support the fixture while adjusting the aircraft cables. An assistant is recommended to complete the remaining steps.

- 1 Feed the aircraft cables through the cable clutches in the canopy.
- 2 Evenly pull the aircraft cable up through the canopy to raise the fixture to the desired length.
- 3 Cut off the excess aircraft cable leaving enough for fine leveling later.




- 4 From front of the canopy remove the cap from the cord grip.




NOTE: The power cord does not support the fixture. For a casual "lazy cord" look, cut the power cord several inches longer than the drop height of the fixture.

- 5 Feed the end of the power cord through the cap, then through the cord grip, and into the canopy.
- 6 Once the desired look is determined, tighten the cap, leave 6 inches of the power cord behind the canopy, and cut off the extra cord.




- 7 Connect the fixture to a suitable ground in accordance with local electrical codes.
- 8 Connect one fixture wire to the neutral power line wire with a wire nut.
- 9 Connect the other fixture wire to the hot power line wire with a wire nut.




- 10 Place all wires and wire nut connections inside the canopy.
- 11 Align the canopy holes with the crossbar holes. Secure the canopy in place by tightening the four screws.

Install the Lamps



- 12** Adjust the aircraft cables until the fixture is level; feed the cable into the cable clutch to raise the fixture and push in on the cable clutch nipple to release the cable and lower the fixture.
- 13** Adjust the bands holding the power cord and aircraft cable to the desired position.



Use **MAX 120 Volt, 60 Watt** type T4, G9 base bi-pin halogen lamp in each socket. 

NOTE: Use only your fingers to replace the lamps.

- 1** Push the new lamp firmly all the way into the socket. Repeat for remaining sockets.

SAVE THESE INSTRUCTIONS!



TECH LIGHTING®

7400 Linder Ave, Skokie, IL 60077
847.410.4400

www.techlighting.com

© 2016 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification.
A Generation Brands Company